thermaltake

ARGENT M5 WIRELESS RGB

Optical Gaming Mouse User Guide

Table of Contents

Table of Contents

Table of Contents

# |Chapter 1:   TT iTAKE Installation

Step 1:
Launch the setup executable file (.EXE) file and click Next.

Step 2:
Click Install to begin the setup process.

Step 3:

Once setup is complete, you will also need to install the Microsoft Visual C++ 2015 Redistributable Package.

※ Without installing the Redistributable Package, the software will fail to launch.

Step 4:

Click Finish to complete the installation.

Chapter 2:   Functions Available on the Home Page

Configuration Pages

Switches between the configuration pages customize key operation, macro recording, lighting effects, performance and battery setting.

Functions for Managing Profiles

Up to 15 profiles can be added for use. The functions Of each button from left to right are:
Add: Create a new profile.
Delete: Delete an existing profile.
Copy: Copy a profile.
Import: Import a profile.
Export: Export a profile.

Correcting the Name of a Profile

The name of a new profile can be modified directly.

Assigning Key Functions

Nine different functions can be assigned.

Restore Mouse Settings for All Keys / Apply

Restore Mouse Settings for All Keys: All key functions saved under the current profile will be restored to factory default values.
Apply: Save and apply all settings to the selected key.

PC IP Address

Use the TT iTAKE APP to enter the IP for control.

Home Page

You can switch the mouse model.

Profiles

The Argent M5 wireless RGB can support up to 6 profiles, which can be switched as required.

Mouse Connected State

Charging : wired mode, support iTAKE setting.
2.4G: wireless mode, support iTAKE setting.
Bluetooth: wireless mode, not support iTAKE setting.

Other Settings / Shrink Window / Close Window

Other Settings: Software version, Amazon Alexa setting and switching the language used for the user interface.
Shrink Window: Close the display and minimize the program to the taskbar.
**Close Window:** Close the display and minimize the program to the lower right corner.

thermaltake

# Chapter 3: Key Configurations

Step 1:

Select a key, then select a "Default" function from the drop-down list.


Step 2:

Click Apply to change and save the new function.

Step 1:

Select a key, then select "Single Key" from the drop-down list.


Step 2:

Enter a new key value into the lower-right box.

Step 3:

Click Apply to change and save the new function.


Step 4:

Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

thermaltake

Step 1:

First, you must designate a key, then select "Macro" in the drop-down list.


Step 2:

Select a macro name from the upper-right.

Step 3:

Select a macro repeat option from the drop-down list located in the lower-right corner.

Step 4:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

thermaltake

Step 1:
Select a key, then select "Media" from the drop-down list.

Step 2:
Select a multimedia function in the right drop-down list.

thermaltake

Step 3:

Click Apply to change and save the new function.

Step 4:

Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

Step 1:

Select a key, then select "Function Keys" from the drop-down list.

Step 2:

Select a type of hotkey function in the upper-right drop-down list.

Step 3:

Select a keyboard function in the lower-right drop-down list.

Step 4:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

thermaltake

Step 1:

Select a key, then select "Launch Application" from the drop-down list.


Step 2:

Select "Application" in the upper-right drop-down list.

Step 3:

Click on the Open File button located on the bottom-right.

Step 4:

Select the executable file (.EXE) to open.

Step 5:

Click Apply to change and save the new function.


Step 6:

Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

Step 1:

Select a key, then select "Launch Application" from the drop-down list.

Step 2:

Select "Web" in the upper-right drop-down list.

thermaltake

Step 3:

Enter the URL into the textbox located on the bottom-right and press Enter.

Step 4:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

Step 1:
Select a key, then select "Gaming Profile" from the drop-down list.

Step 2:
Select a game title in the upper-right drop-down list.

Step 3:

In the lower-right drop-down list, select an in-game action.


Step 4:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

Step 1:
Select a key, then select "Mouse" from the drop-down list.

Step 2:
Select a mouse function in the right drop-down list.

Step 3:
Click Apply to change and save the new function.

Step 4:
Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

thermaltake

Step 1:

Select a key, then select "Disable" from the drop-down list.

Step 2:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

Chapter 4: Functions Available on the Macro Page

## New Macro / Delete / Copy / New Text / Import / Export

New macro: Create a new macro.
Delete: Delete a macro or text.
Copy: Copy a macro or text.
New text: Create a new text.
Import: Import a macro or text.
Export: Export a macro or text.

Modifying the Name of a Macro / Text

You can change the name of a new macro or text directly.

Macro Recording Settings

Record Delay Times: Record a macro based on the time interval between each keystroke.
Fixed Delay: Record a macro based on the specified time interval.
No Delay: Record a macro without recording the time interval between each keystroke.

Macro Recording Area

You can verify the sequence recorded by the macro and the key assignment.

Record / Delete / Insert / Pause / Edit

Record: Begin macro recording.
Delete: Delete the assigned value of a specific key.
Insert: Insert an additional value above or below the existing value of a specific key.
Stop: End macro recording.
Edit: Edit the delay time of a specific key.

Chapter 5: How to Record Macros

Step 1:
Add a new macro and modify its name.

Step 2:
Select the delay method used to record the macro by using the checkboxes below.

Step 3:
Press the Record button.

Step 4:
Enter the sequence to be recorded from the keyboard, then press the Stop button to complete the recording.

Step 1:

Select a macro by clicking on the key it is assigned to.

Step 2:

Click the Insert button.

Step 3:

Select the position where new content is to be inserted.

Step 4:

Press the Record button.

Step 5:
Enter the sequence to be recorded from the keyboard.

Step 6:
Click the Stop button to complete the insertion process.

Step 1:

Add a new text set and modify its name.

Step 2:

Enter the values for the "Start Key" and "End Key" in the upper right corner.

thermaltake

Step 3:

Click on the input box located at the bottom-right corner and enter the characters to be recorded from the keyboard.

Step 4:

Click the Save button to complete the recording of the text set.

thermaltake

Chapter 6: Functions Available on the Lighting Effects Page

Lighting Effects

Mouse light of 6 lighting effects are supported: Static, Pulse, Blink, Wave, RGB Spectrum, Reactive.

Lighting Effects Configurations

Can be used to adjust the color, direction, speed, and brightness level of the lighting effect within an area; can also be used to switch to random colors.

Apply / Restore Lighting Effect Settings

Apply: Apply the new lighting effect settings on the mouse.
Restore Lighting Effect Settings: All lighting effect settings saved under the current profile will be restored to factory default values.

Color Pattern Settings

Add Pattern: Add a new pattern with red to black gradient.
Delete Pattern: Delete the currently selected color pattern.
Insert Color Point: Add a red color point to the color pattern.
Delete Color Point: Delete the selected color point from the color pattern.

Color Wheel Settings

You can select a color from the color wheel directly or enter RGB color values to adjust the color of the lighting effect.

# Chapter 7:   Lighting Effects Overview

Step 1:
Select "Static" in the Lighting Effect drop-down list and select effect areas.

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

thermaltake

Step 3:

Adjust the brightness level of the mouse's backlight.

Step 4:

Click Apply to save the new settings.

Step 1:
Switch the zones to "Customized."

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Click on the mouse image directly with the left mouse button to change the color.

※ Right click to cancel the color.

Step 4:

Click Apply to save the new settings.

thermaltake

Step 1:

Select "Pulse" in the Lighting Effect drop-down list and select effect areas.

Step 2:

Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Adjust the backlight speed.

Step 4:

Click Apply to save the new settings.

Step 1:

Switch the zones to "Customized."

Step 2:

Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Click on the mouse image directly with the left mouse button to change the color.

※ Right click to cancel the color.

Step 4:

Click Apply to save the new settings.

thermaltake

Step 1:
Select "Blink" in the Lighting Effect drop-down list and select effect areas.

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:
Adjust the backlight speed.

Step 4:
Click Apply to save the new settings.

thermaltake

Step 1:

Switch the zones to "Customized."

Step 2:

Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Click on the mouse image directly with the left mouse button to change the color.

※ Right click to cancel the color.

Step 4:

Click Apply to save the new settings.

Step 1:

Select "Wave" in the Lighting Effect drop-down list.

Step 2:

Select a set of color patterns on the upper-right.

Step 3:

Set the direction, speed, and brightness level of the lighting effect.

Step 4:

Click Apply to save the new settings.

Step 1:

Add a new set of color patterns.

Step 2:

Add a new color-insertion point and drag it to the desired position.

Step 3:

Click on each color-insertion point to modify its color.

Step 4:

Click Apply to save the new settings.

Step 1:

Select "RGB Spectrum" in the Lighting Effect drop-down list and select effect areas.

Step 2:

Set the speed and brightness level of the backlight and click on Apply to save the new settings.

Step 1:

Select "Reactive" in the Lighting Effect drop-down list and select effect areas.

Step 2:

Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Adjust the backlight speed.

Step 4:

Click Apply to save the new settings.

Step 1:

Switch the zones to "Customized."

Step 2:

Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Click on the mouse image directly with the left mouse button to change the color.

※ Right click to cancel the color.

Step 4:

Click Apply to save the new settings.

Chapter 8: Functions Available on the Performance Page

Sensitivity Stage

You can switch up to 6 different sensitivity stages which you can cycle through using the DPI cycle button.

Enable X-Y Sensitivity: By default, the X-axis(horizontal) and Y-axis(vertical) use the same sensitivity values. However, you may set different sensitivity values to each of the axes by the Enable X-Y Sensitivity option.

Polling Rate

The higher the polling rate, the more often the computer receives information about the status of your mouse, thus increasing the mouse pointer's reaction time.

Button Response

The lower the response, the fast often the computer receives information about the status of your mouse, thus decreasing the mouse button reaction time.

Angle Snapping

Angle Snapping corrects minor imperfections when you try to move your mouse in straight horizontal or vertical paths. This can increase precision if you are simultaneously turning and shooting in a first person shooter or drawing lines in a graphics editing application.

Chapter 9: Functions Available on the Battery Page

Battery State

100 - 80% : Green Color.
80 - 50% : Yellow Color.
50 - 20% : Orange Color.
< 20% : Red Color.

Wireless Power Saving

Enter the sleep mode after inactivity.
Support 10, 30, 60, 300, 600, 900 Sec.

Low Power Notification

Setting the low power notification.
Support 10%, 15%, 20%, 30%.

Chapter 10: Functions Available on the Settings Page

Language Settings

Sets the language of the program's user
Interface and theme.

Razer Chroma On / OFF

Users who have installed both the TT iTAKE Software
and Razer Synapse 3 can experience synchronized
gaming and RGB lighting effects on their gaming gear.

Amazon Alexa Login

TT iTAKE software support Amazon Alexa voice
service, allowing you to control the lights by talking
to the Alexa Enabled device.

TT iTAKE APP Password Setting

Enter four number or English alphabet.

※ Empty is disable function.

Official Website / Social Media

Official Website: Visit the Product official website.
Social Media: Visit Thermaltake on Facebook.

Software Version

Software Version: Displays the version number of the installed program.

|Chapter 11:   Alexa Voice Control Table

Basic Command			Color command
Wake up Alexa	**Command**	**Light Mode**	**Color**
Alexa tell / ask / open Thermaltake	Use / Switch / Change	Static Mode Pulse Mode RGB Spectrum Mode Raindrop Mode Blink Mode	in Red color
			in Orange color
			in Yellow color
			in Green color
			in Blue color
			in Indigo color
			in Purple color
			in White color
			in Rainbow color
		Wave Mode Temperature Mode Hello TT Mode	Preset modes with no color options.

thermaltake