

| Content 1

Main Interface



Profile Selection

1. Lighting
2. Customize
3. Macro

New Profile

Open Profile

Device

Setting Area

Open Menu/Add Profile/
Delete Profile/Export Profile/Import Profile/Copy Profile/
Reset Profile

Setting/Minimize/Close
(Close and hide to task icon)

Keyboard (Lighting
Effect, Key
Customize)

| Content 2

Lighting Effects



Keyboard (Lighting Effect)

Lighting Effects:
Sync: Sync
Challenger Elite
keyboard and
Mouse Lighting
effects.

1. Lighting Brightness
2. Lighting Speed

| Content 3

Key Customize

Game Mode Key :


Turn on Game Mode via clicking Game Mode Key on keyboard

Fn Key :

Cannot setup Fn Key

Customize List :

1. Click to open list:
2. Reset/Keyboard Key/Mouse Key/ Mouse Wheel/Rapid Fire/ Multimedia/System/Macro
3. Please Note:
Game Mode must be turned on to activate customized key function.





Reset:

1. Reset selected key setting to default
2. Click Apply to confirm

Mouse Key:

1. Click to open: (Left Click/Middle Click/Right Click/Forward/Backward)
2. Click Apply to confirm

Rapid Fire:

1. Enter value between each click (Maximum 255)
2. Enter number of click (Maximum 255 clicks)
3. Click Apply to confirm

System:

1. Power
2. Sleep
3. Wake
4. Click Apply to confirm

Keyboard Key:

1. First click on the desired key to setup
2. Please Enter Key: Above example shows the original S key is now C key.
(Yellow Highlight indicates customized key)
3. Click Apply to confirm

Mouse Wheel:

1. Mouse Wheel: Select Scroll Up/Down
2. Scroll: Enter scroll value, maximum 127
3. Click Apply to confirm

Multimedia:

1. Media Player/Play/Pause/Previous Track/Next Track/
Volume Down/Volume
Up/Mute/Website/Refresh/Stop/
Previous Page/Next Page/Bookmarks/Search/My
Computer/Calculator/Mails
2. Click Apply to confirm

Macro:

1. Select Macro
2. Select Macro Finish: Standard/Release/Click/
Stop after release/Cycle (Enter cycle value below)
3. Click Apply to confirm

| Content 4 Macro Interface/Setting



Macro Selection

Enter Macro Name

Add/Delete Macro

The screenshot shows the Macro Interface with a list of recorded macro actions and a configuration panel for a selected action. The list has columns for KEY, ACTION, and DELAY(ms). The configuration panel has fields for KEY, TYPE, and DELAY, along with navigation and control buttons.

KEY	ACTION	DELAY(ms)
T	↓	70
T	↓	100
E	↓	90
E	↓	120
S	↓	70
S	↓	140
P	↓	70
P	↓	100
O	↓	90

Configuration Panel:

- KEY: T
- TYPE: DOWN
- DELAY: 7 x 10ms

Buttons: ↑, ↓, ↕, 🗑️, 🎮, SAVE, CANCEL

1. Change Macro Name
2. Mouse Action (Click to open action list, click again to close mouse action window)
3. Start Recording: Click to start Macro recording, click Stop Recording to stop

1. Top: Move to top
2. Bottom: Move to bottom
3. Move Up
4. Move Down
5. Delete Macro action
6. Clear all Macro action
7. Save: Save Macro
8. Cancel: Cancel Macro

Recorded Macro Action List

1. Key: Keyboard/Mouse
2. Action: Keyboard/Mouse action
3. Delay: Action delay

1. Key: Change key action
2. Type: Action selection (Key press Up/Down)
3. Delay: Delay time between each action



THANK YOU